

Figure 20



FIGURE 20.—Sectional Chart Excerpt.

NOTE: Chart is not to scale and should not be used for navigation. Use associated scale.

Figure 15

TAF

KMEM 121720Z 1218/1324 20012KT 5SM HZ BKN030 PROB40 2022 1SM TSRA OVC008CB
FM2200 33015G20KT P6SM BKN015 OVC025 PROB40 2202 3SM SHRA
FM0200 35012KT OVC008 PROB40 0205 2SM-RASN BECMG 0608 02008KT BKN012
BECMG 1310/1312 00000KT 3SM BR SKC TEMPO 1212/1214 1/2SM FG
FM131600 VRB06KT P6SM SKC=

KOKC 051130Z 0512/0618 14008KT 5SM BR BKN030 TEMPO 0513/0516 1 1/2SM BR
FM051600 18010KT P6SM SKC BECMG 0522/0524 20013G20KT 4SM SHRA OVC020
PROB40 0600/0606 2SM TSRA OVC008CB BECMG 0606/0608 21015KT P6SM SCT040=

FIGURE 15.—Terminal Aerodrome Forecasts (TAF).

Figure 21



FIGURE 21.—Sectional Chart Excerpt.

NOTE: Chart is not to scale and should not be used for navigation. Use associated scale.

Figure 2




FIGURE 2.—Load Factor Chart.

Figure 15

| TAF | |
|------|---|
| KMEM | 121720Z 1218/1324 20012KT 5SM HZ BKN030 PROB40 2022 1SM TSRA OVC008CB FM2200 33015G20KT P6SM BKN015 OVC025 PROB40 2202 3SM SHRA FM0200 35012KT OVC008 PROB40 0205 2SM-RASN BECMG 0608 02008KT BKN012 BECMG 1310/1312 00000KT 3SM BR SKC TEMPO 1212/1214 1/2SM FG FM131600 VRB06KT P6SM SKC= |
| KOKC | 051130Z 0512/0618 14008KT 5SM BR BKN030 TEMPO 0513/0516 1 1/2SM BR FM051600 18010KT P6SM SKC BECMG 0522/0524 20013G20KT 4SM SHRA OVC020 PROB40 0600/0606 2SM TSRA OVC008CB BECMG 0606/0608 21015KT P6SM SCT040= |

FIGURE 15.—Terminal Aerodrome Forecasts (TAF).

Figure 26




FIGURE 26.—Sectional Chart Excerpt

NOTE: Chart is not to scale and should not be used for navigation. Use associated scale.

Figure 21




FIGURE 21.—Sectional Chart Excerpt.

NOTE: Chart is not to scale and should not be used for navigation. Use associated scale.

Figure 22




FIGURE 22.—Sectional Chart Excerpt.

NOTE: Chart is not to scale and should not be used for navigation. Use associated scale.

Figure 20



FIGURE 20.—Sectional Chart Excerpt.

NOTE: Chart is not to scale and should not be used for navigation. Use associated scale.

Figure 12

| |
|--|
| METAR KINK 121845Z 11012G18KT 15SM SKC 25/17 A3000 |
| METAR KBOI 121854Z 13004KT 30SM SCT150 17/6 A3015 |
| METAR KLAX 121852Z 25004KT 6SM BR SCT007 SCT250 16/15 A2991 |
| SPECI KMDW 121856Z 32005KT 1 1/2SM RA OVC007 17/16 A2980 RMK RAB35 |
| SPECI KJFK 121853Z 18004KT 1/2SM FG R04/2200 OVC005 20/18 A3006 |

FIGURE 12.—Aviation Routine Weather Reports (METAR).

Figure 23



Figure 25

